



Camera Monitoring &
Notification Software

Owner's Manual

&

Quick Start Guide

Welcome to ReCam Software

Welcome to the ReCam® Camera Monitoring & Notification software by MOBI Technologies, Inc. ReCam is designed to help you easily monitor your home or business from anywhere in the world.

You can maximize its use and benefit by reviewing the included Help files and ReCam's web page at www.getmobi.com/recam.php to familiarize yourself with many of its features.

About ReCam

ReCam captures images up to 30 frames per second from any video device, including USB cameras, analog cameras connected to a capture card, TV-boards, camcorders with FireWire (IEEE 1394) interface, and Network cameras. The program broadcasts captured live audio and video content in real time to client computers from either your computer or through any FTP server.

Viewers can watch real video and audio using an Internet browser or another copy of the ReCam program.

When the program detects motion in the monitored area, it can sound an alarm, e-mail you the captured images, start broadcasting, or record a video.

The program has features to add text-captions and image-logos to the images, place a date/time stamp on each video frame, and to adjust the frame rate, picture size, and quality.

About the registration key

The registration key is a twenty-five-digit alpha-numeric code located on the ReCam CD jacket. Do not lose this code.

Important You must enter the registration key after the installation, or the software will run in trial mode.

The installation code ensures adherence to the single user license agreement, which allows for use of one (1) copy of the software on a single computer at a time.

Registration and customer support

Please take time to register your product during installation through the MOBI Technologies, Inc. web site at www.getmobi.com/recam.php

For information about technical support and customer service, please visit www.getmobi.com/recam.php or choose the **Help** menu from the ReCam software. The help menu will have options available, such as a user manual, answers to Frequently Asked Questions, and trouble shooting information. Unlimited support for installation will be provided via e-mail or telephone with your registration key. For sales or installation support we can be reached at 310-551-1120 Mon.-Fri. 9am-5pm PST.

Installation & Quick Start

Before you begin the installation process, exit other open programs, and save your work. For updated information about ReCam, visit www.getmobi.com/recam.php

Installation notes

Before you install ReCam, review the following notes:

To install ReCam in Windows NT, XP, or 2000 Professional, you must log on with Administrator or Power User privileges.

If an old version of ReCam software is already installed on your computer, you can install the newer version without uninstalling the old one.

If your computer is running virus protection software, disable it before installing ReCam software, and turn it back on after installation.

By default, ReCam software will be installed in the C:\Program Files\ReCam folder. During installation, you can choose another drive or folder for the install.

Installing ReCam software

You must use the installation program to install ReCam software—you can't install ReCam software by dragging files to your hard disk.

To install ReCam on your hard disk:

1. Insert ReCam CD into your CD or DVD drive
2. Follow the on-screen instruction to complete installation

Quick Start (IP Camera setup)

1. Select **File** on the Menu Bar
2. Select **New Camera**
3. Select **Network IP Camera** from the video device list
4. Choose your IP camera from the **Camera Model** drop down list (In most cases even if your specific camera brand or model is not listed you can access the camera via ReCam by just entering its IP address)
5. Enter the **IP address** and **Port** for your camera
6. Enter the **User Id** and **Password** if applicable
7. Click **Connect to Camera**
8. Click **Ok**

Notes: By default cameras added will have the “Enable Live Recording” feature in the “Recording” tab activated for continuous recording.

All camera settings or profiles can be saved as sessions that can be reloaded automatically.

Certain models may not be compatible with ReCam software. Please check www.getmobi.com/recam.php for a list of incompatible IP cameras.

Quick Start (USB Camera setup)

Note: Before you create a new local camera, make sure its driver is installed on your computer. Consult your Camera's user manual for proper installation.

1. Select **File** on the Menu Bar
2. Select **New Camera**
3. Select **Local Camera** the video device list
4. Select your camera from the **Video Devices** list. *(If the camera isn't installed properly, it will not show up here)*
5. Click **OK**

USB Video Capture Device (Optional)

If you purchased ReCam with the optional USB Video Capture adaptor, you must install the adaptor and its driver. Please follow the USB adaptor's installation instructions for proper installation & configuration. After installation, you can access the device from ReCam by selecting Local Camera and choosing the Capture device under the Video Devices drop down list in the Camera Settings area.